

# **Electronic Vibration Switch (EVS)**



### **Features**

- Piezoelectric-crystal internal sensor with built-in microelectronics for reduced noise sensitivity
- Electronically integrated output signal that measures and trips on velocity
- Adjustable calibrated set-point controls
- Shutdown set-point measured in velocity
- 4-20 mA output for continuous monitoring capability
- Solid-state outputs for setpoint trip
- Adjustable time delay to prevent false tripping on high-vibration start-ups or non-repetitive transient events
- Self-test and calibration

The Electronic Vibration Switch (EVS) protects against equipment failure by monitoring velocity-based vibration levels and providing an early warning or shutdown when abnormal vibration is detected.

The EVS product can be connected to Murphy's TTD™ annunciator, Centurion™ or Millennium™ controllers for increased functionality. It also complements Murphy's VS2™ switch, which is designed to detect an abnormal shock or excessive vibration due to equipment failure and to shutdown other equipment in a system to prevent further damage.

NOTE: For proper operation, refer to document "00-02-0744 - EVS Installation and Operations Manual".

The EVS product can be used on any equipment where abnormal vibration could lead to equipment damage, including:

- · Cooling fans
- Engines
- Pumps
- Compressors
- Gear boxes
- Motors
- · Generator sets

The EVS product can monitor and alert the operator of abnormal vibration caused by a variety of possible factors, including:

- · Imbalance and misalignments
- · Worn sleeve bearings
- Broken tie down bolts
- Worn ball or roller bearings
- · Gear mesh
- Blade pass frequencies
- Detonation
- · Broken parts


### **How to Order**

A=Analog (24VDC external power, switch and 4-20mA output)

S=Standard (24VDC external power, switch only)

EVS Product Table				
Model	Power	Bandwidth	Analog Out	Area Classifica- tion
EVS-A	24 VDC	6-500Hz	Yes	CL I, Div 2, Gr B,C,D
EVS-S	24 VDC	6-500Hz	No	CL I, Div 2, Gr B, C, D

## **Product Dimensions and Sensitivity Axis**



## **Specifications**

**Environmental** 

- Operating Temperature:-40°F to 185°F (-40°C and +85°C). Humidity: 0-95% non-condensing
- Vibration: 30 g's (Mechanical stability)

**Power Requirements** 

### Murphy EVS-A, EVS-S - External DC Power

External power: 8-32 VDC

Input Current: 100mA Max

**Product Accuracy** 

- ±5% of full scale at 1.5 ips and 21 deg C.
- ±5% Variation over temperature from 21 deg C, over operating range.
- Integration Stage End-to-End Noise: <0.01 ips RMS

Murphy EVS-A and EVS-S

- $\pm 5\%$ , at Bandwidth of 6 to 500 Hz from 50Hz calibration point  $\pm 3$ dB at Bandwidth of 3 to 875 Hz, worst case

**Trigger Feature** 

- Trigger level between 0.1 and 1.5 inches per second (ips) Peak
  Trigger set with single turn adjustable PC board mount potentiometer
- PC board marked with 15 marks corresponding to 0.1 to 1.5 in 0.1 increments

- <u>Time Delay Feature</u>
   Adjustable from 0 to 10 seconds
- Set with adjustable single turn PC board mount potentiometer
- PC board marked with 11 marks corresponding to 0 to 10 seconds in 1 second intervals

**Output** 

- Normally-Open and Normally-Closed outputs simultaneously available
- Open-collector outputs sink to Common Ground

50 mA sink capacity

- Input voltage: 40 VDC maximum
- Switch output is selectable for latched or non-latch configurations. Reset accomplished by reset pushbutton or external contact closure when in latch mode.
- Shutdown Alarm activated on power loss

# LED Outputs Alarm LED output

- Red LED
- LED strobing for first 5 minutes after entering Alarm mode
- Flashing thereafter until Reset activated
- Strobe rate: 2mSec on, every 0.5 ±0.25 seconds
- Flash rate: 2mSec on, every 6 ±1 seconds

#### Power LED output

- Green LED
- Flash Duration: 2mSec

### Murphy EVS-A and EVS-S

Flash once every 6 ±1 seconds

#### 4-20mA output (EVS-A only)

- Power obtained from power supply Loop Resistance: 600 ohms max at 24 V and 20mA.
- Current loop accuracy ±5% from internal setpoint
- 20 ma corresponds to 1.5 ips Peak
- 4 ma corresponds to 0 ips Peak

### Reset

- Local reset switch w/momentary contact
- External reset: Available via header and will require an external relay or pushbutton contact to ground to activate the reset.
- Activation Period: Reset must be active for 0.5 sec. minimum to reset the switch.

**Circuit Functional blocks** 

Charge Amp interface Band-aids Filter Integration

- The input Transducer is an integrated PZT element for measuring acceleration with an internal charge converter.
- Maximum G level of 13 g's at 500hz

### **Band-aids Filter**

Frequency response dependent on model number (refer to "Product Accuracy")

Integration

Integration to convert from G to IPS peak

**Approvals** 

EVS-A and EVS-S - Class 1 Div 2 Hazardous Area, Groups B, C, D



美国摩菲Murphy代理商:

信德迈科技(北京)有限公司

CNMEC Technology (Beijing) Co.,Ltd.

地址:北京朝阳区望京SOHO-T1-C座2115室

邮编:100102

电话: 010 - 8428 2935, 8428 9077

13910962635

传真: 010 - 8428 8762 Email: sales@cnmec.biz

Website: Http://www.cnmec.biz

Warranty - A limited warranty on materials and workmanship is given with this FW Murphy product. A copy of the warranty may be viewed or printed by going to http://www.fwmurphy.com/warranty