


# Wiring Harness Accessories

## PowerView™ PV101 and PVM Gages

### Diagram

Use this easy-connect diagram to help you locate the wiring harness you need.





**NOTE:** The PV101 can support up to five PVM gages in a distance less than 8.5 meters.



### How to Order

Part Number	Length	Model: Description	Diagram
78000124	12 in. (305 mm)	PVW-P-length: CAN and power harness for PowerView module (includes 120Ω CAN resistor)	
78000479	9 in. (229 mm)	PVWM-J-length: Gage harness	
78000490	12 in. (305mm)		
78000503	24 in. (607 mm)		
78000481	9 in. (229 mm)	PVWM-JM-length: PowerView jumper harness	
78000504	12 in. (305mm)		
78000505	24 in. (607 mm)		

## How to Order - continued

Part Number	Length	Model: Description	Diagram
78000157	72 in. (1.82 m)	PVW-CH-length: PowerView CAN extension harness	
78000158	144 in. (3.65 m)		
78000159	240 in. (6.10 m)		
78000160	360 in. (9.10 m)		
78000149	72 in. (1.82 m)	PVW-PH-length: PowerView battery power extension harness	
78000150	144 in. (3.65 m)		
78000151	240 in. (6.10 m)		
78000152	360 in. (9.10 m)		
78000480	-	PVMJR: Terminating Resistor (use on last PVM gage in a series - not needed for PV101)	
78000511	12 in. (305 mm)	PVWM-K-length: PV101 - PVM Wiring Kit includes: one PVW-P, four PVWN-J, one PVWM-JM, one PVMJR	 <p>(1) PVW-P</p> <p>(4) PVWM-JM</p> <p>(4) PVWM-J</p> <p>(1) PVMJR</p>
78000512	24 in. (607 mm)		
78000125	30 in. (762 mm)	PVW-PW-length: PowerView CAN & Power Loose Wiring (includes 120Ω CAN resistor)	 <p>Length: 30 in. (762 mm)</p>
78000127	24 in. (607 mm)	PVW-CC-length: PowerView CAN Loose Wiring	 <p>Length: 24 in. (607 mm)</p>
78000126	24 in. (607 mm)	PVW-PC-length: PowerView Power Loose Wiring	 <p>Length: 24 in. (607 mm)</p>
00009510	-	PVW-CT: CAN bus tee Wiring Harness	